



Application:

In areas between pipe flashing and pipe - Apply first coat of ASC 7 Elastomagic Cement with brush or trowel at 1/8-1/4 inch thickness. Immediately following embed ASC F Polyester Fabric. Lightly brush the polyester fabric into ASC 7 to achieve full saturation, smoothing out wrinkles or voids. Apply second coat of ASC 7 Elastomagic Cement, ensuring the polyester fabric is completely covered around the pipe / flashing detail (ASC 3 Course Method).

As needed repeat procedure between Base Flashing and Existing Roof Deck.

Pipe Flashing



Issue Date:
07/02/19

Not To Scale

Detail No.
ASC-TD-0111