



Pre-Application:

Wall Scuppers: Remove loose, flaking or existing waterproof coatings, including mastic and asphalt. Roof Drains: Remove existing roof membrane. Replace removed membrane with new modified bitumen cap sheet.

Application:

Apply first coat of ASC 7 Elastomagic Cement with brush or trowel at 1/8-1/4 inch thickness. Immediately following embed ASC F Polyester Fabric. Lightly brush the polyester fabric into ASC 7 to achieve full saturation, smoothing out wrinkles or voids. Apply second coat of ASC 7 Elastomagic Cement, ensuring the polyester fabric is completely covered around the existing roof drain and Scupper. (ASC 3 Course method).



Existing Roof Drains and Through Wall Scuppers

Issue Date:
07/02/19

Not To Scale

Detail No.
ASC-TD-0112