



Application:

In the area between Skylight / Curb flashing - Apply first coat of ASC 7 Elastomagic Cement with brush or trowel at 1/8-1/4 inch thickness. Immediately following embed ASC F Polyester Fabric. Lightly brush the polyester fabric into ASC 7 to achieve full saturation, smoothing out wrinkles or voids. Apply second coat of ASC 7 Elastomagic Cement, ensuring the polyester fabric is completely covered around the Skylight or Curb Flashing (3 Course Method).

Install roof renewal system over the applied new 3-coursing, reaching the vertical portion of the Skylight or Curb Flashing.

**Existing Curb Flashings for Skylights
or Other Fixtures With Exposed Metal Flanges**



Issue Date:
07/02/19

Not To Scale

Detail No.
ASC-TD-0113