



Application:

Apply first coat of ASC 7 Elastomagic Cement with brush or trowel at 1/8-1/4 inch thickness. Immediately following embed ASC F Polyester Fabric. Lightly brush the polyester fabric into ASC 7 to achieve full saturation, smoothing out wrinkles or voids. Apply second coat of ASC 7 Elastomagic Cement, ensuring the polyester fabric is completely covered.



3 Course Installation Method:
ASC 7 Elastomagic Cement and ASC F Polyester Fabric

Issue Date:
07/02/19

Not To Scale

Detail No.
ASC-TD-0117